

wallpaper hack

Check out this easy wallpaper hack. All it takes is a kitchen sponge. If you like the pattern on a particular wallpaper but it's not the right colour or scale, why not use it as inspiration for your own paint project? We took two of the latest wallpapers from the Resene Wallpaper Collection (designs 34244-2 and 34244-3), and did our own painted version.

you will need:

- Resene SpaceCote Low Sheen in Resene Quarter Friar Grey – enough to do two coats on your wall
- Resene testpots or tins (depending on the size of the area you're decorating) of Resene Triple Friar Grey and Resene Half White Pointer
- Kitchen sponges
- Ruler, level, pencil or chalk, pen and scissors
- Small brush

Prep: Paint the background wall colour. We used Resene SpaceCote Low Sheen in Resene Quarter Friar Grey.

Above: Clever mimicry of a current wallpaper design using Resene Half White Pointer and Resene Triple Friar Grey sponge prints on a Resene Quarter Friar Grey wall. The pots are painted in Resene Quarter Friar Grey and Resene Triple Friar Grey, the ladder has a distressed effect using Resene Half White Pointer and the floorboards are in Resene Colorwood Greywash.



Resene Triple Friar Grey

Resene Quarter Friar Grey Resene Half
White Pointer

Resene Colorwood Greywash **styling** Megan Harrison-Turner **pictures** Bryce Carleton