



Cut in cleanly using an angled cutting -in brush, small am<mark>ounts of paint at</mark> a time and steady cont<mark>inuous strokes</mark>

# YOU WILL NEED

### FEATURE WALLS: Resene SpaceCote Flat waterborne enamel in Resene Spotlight

#### NEUTRAL WALLS: Resene Zylone Sheen waterborne low sheen in Resene Rice Cake

## WOODWORK: Resene Lustacryl semi-gloss waterborne

#### DOOR:

Resene Enamacryl gloss waterborne enamel in **Resene Black** 

PLUS: Ladder, gloves, dust sheets and various paint brushes and rollers

**Step 2** Stir the paint, pouring some into a roller tray and more into a paint pot or other small container that's easy to hold while cutting in or climbing up and down the ladder.

Step 1 Prepare your walls for

imperfections with bog, lightly

sanding once it is dry. Check all

surfaces are smooth and free of

painting, filling any holes or

dust - including woodwork.

**Step 4** Once dry, sand any dribbles and give it a second, and if necessary, a third coat.

**Step 3** Cut in around the edges

amounts of paint. Give the body

of the wall, using an angled

cutting-in brush and small

of the wall a first coat.



Call 0800 RESENE (737 363) visit www.resene.co.nz or email advice@resene.co.nz



the paint the professionals use

Make a simple
coat rack using
a wood offcut and
assorted hooks,
painted in a glossy black.
Once dry, mount hooks
and screw securely to wall

