



25mm galvanised jolt head nails Cardboard Drill with 10mm drill bit Hammer **Jigsaw** Offcuts of 9mm and 15mm treated plywood Paintbrush Pencil

PVA glue (exterior) Resene Lustacryl tinted to Resene Elvis Resene Quick Dry Ruler Sandpaper Saw Scissors



Mark two pieces of 15mm plywood measuring 300mm x 150mm and two pieces measuring 170mm x 150mm. Mark one piece of 9mm plywood measuring 300mm x 200mm.



Cut the pieces of plywood using pencil lines as a guide.



Smooth any rough edges with sandpaper.



On a flat surface, assemble the sides of the box, as Attach the base to the box, fixing with PVA glue and shown, fixing along each edge with PVA glue and 25mm nails. 25mm nails





Draw a curved handle template, as shown, on a piece of cardboard.



Cut out the template with scissors.



Place the template on a piece of 9mm plywood and trace around the edge, as shown. Reposition the template and trace a second handle.



Cut out both handles with a jigsaw and smooth any rough edges with sandpaper.



and fix the two handles into position, as shown, and allow two hours to dry. attaching with PVA glue and 25mm nails.



Drill six 10mm drainage holes in the base of the box Apply one coat of Resene Quick Dry to the peg box



Apply two coats of Resene Elvis to the peg box, allowing two hours for each coat to dry.



For more on paints phone 0800 RESENE (0800 737 363) or visit your Resene ColorShop or www.resene.co.nz

HERE'S ANOTHER **OPTION:**

Create a fun gold effect by painting the peg box with one coat of Resene Porsche followed by two coats of Resene Bullion.

TO GET THE LOOK:

Mark painted the background shed wall with Resene Lumbersider tinted to Resene Soft Apple.