

















Step 1

Measure up and cut your timbers to size, using a drop saw or handsaw.

Step 2

Oil stain each timber on all sides with a first coat. I chose to use Resene Woodsman Penetrating Oil Stain in Pitch Black.

Step 3

Measure 15mm from the top and bottom of each 1400mm timber, and pre-drill.

Step 4

Screw the 200mm timber pieces in place with the 65mm stainless screws. Screw together to make 2 frames.

Step 5

Measure 35mm from the top of the frame to secure the remaining 200mm timbers, and pre-drill.

Step 6

Screw the 200mm timbers in place.

Step 7

Apply a second coat of stain.

Step 8

Using the 25mm stainless steel screws, attach your wire or strap in a diagonal cross at the top of the frame.

Step 9

Loop the cable of the outdoor pendant over the cross. Your light is ready. ■



Jane Horne and partner Simon Bartholomew design and develop projects from their studio (plainandsimple.co.nz) in Christchurch, managing projects throughout the South Island.