

















# Step 3 Fill the larger pot to over halfway with the concrete mix.

#### Step 4

Put the smaller pot in to the mix (without it touching the bottom of the larger pot). Fill up the larger pot with more concrete, if necessary, until it reaches near the top of the pot. Tap around the larger pot with your hand to release any air bubbles.

Step 5
On a flat surface, put the weights into the smaller pot and anchor down as

necessary. Allow to cure as per the manufacturer's instructions.

#### Step 6

Once set, remove the weights and pull on the pots to release from the concrete. A gentle tap can help. Sand down any rough edges.

### Step 7

Drill a hole in the centre of the pot for drainage.

### Step 8

Coat the pot with Resene Walk-On Concrete Clear in Clear Satin.



Jane Horne and partner Simon Bartholomew design and develop projects from their studio (plainandsimple.co.nz) in Christchurch, managing projects throughout the South Island.



## Get decorating with Resene plant-based paints and stains!

At Resene we're committed to producing paints and stains that lessen the impact they have on our environment. Which is why we've developed a range of new plant-based products that are made using plants and minerals.

Available now at your local Resene ColorShop!



To find out more visit: resene.co.nz/plantbased

# Resene

the paint the professionals use your paint and colour experts!