



MATERIALS

You will need • 1.2m - 200mm
x 25mm dressed pine • 5 x size 15
terracotta pots • 2.5m length of #8
wire or similar • 1 bag of concrete
• Green felt • 3.2m - 6mm vinyl
tubing • Washi or electrical tape
• Paper & pencil • Jigsaw • Sander
and fine sandpaper • Drill and drill
bit • Wood glue • Resene Quick Dry
Primer, test pots and brushes
Cost: \$76 excluding paint

Find a suitable flamingo image online, copy and mark out onto the timber. Cut out carefully using the jigsaw. Sand well.

2 Undercoat with Resene Quick Dry Primer and when dry apply two topcoats to the body. I used Resene Test pots in Smitten, with White and Black for the beaks.

Undercoat the terracotta pots including the inside rim. Apply 2 topcoats. I used Resene Test pots in White, Abbey Road, Vanilla Ice, Half Dusted Blue and Ciderhouse.

4 Cut the wire into 10 x 250mm lengths. Drill two angled holes into the base of the bodies of each bird. Put a drop of glue into each hole and insert the wire legs. Allow to dry.

With suitable safety gear on, mix concrete. Put a stone to block the drainage hole and pour the concrete into each pot. Insert the bird's legs into the concrete, ensuring the bodies are level, and allow to dry.

6 Cut felt circles to cover the concrete, with slits to accommodate the legs. Cut the vinyl tubing into 400mm lengths and join the ends by melting over a candle or similar. Allow to cool and wrap the rings with electrical or Washi tape in various colours.

What colour should I stain my fence?

What paint is best for terracotta pots?

How do I prep my deck before staining it?

Can I protect colour from sun damage?

Is there a special paint for swimming pools?

How do I stop people skidding on my path?

For helpful advice on your paint, stain and decorating projects, see your local Resene ColorShop or ask an expert free online:

Ask a Tech Expert resene.co.nz/technicalexpert Ask a Colour Expert resene.co.nz/colourexpert



www.resene.co.nz/colorshops