



Difficulty level ★ easy ★★ moderate ★★★ challenging

Resene art with Mark Rayner – 7



This cool green tiki sculpture would look great in any retro pad.

You will need:

- 17mm plywood cut to the following dimensions:
1 @ 280mm x 200mm
2 @ 166mm x 90mm
2 @ 280mm x 90mm
- Hammer
- Paintbrush
- Panel pins
- PVA wood glue
- Resene LumberSider tinted to Resene Woodstock
- Resene Multishield+ Gloss
- Resene Quick Dry Acrylic Primer Undercoat
- Sandpaper
- Wooden tiki mask



Step one

Assemble the four pieces of plywood to form a low plinth. Fix together with PVA and panel pins.

Step two

Lightly sand the edges to remove any splinters.

Step three

Prime the plinth with one coat of Resene Quick Dry Acrylic Primer Undercoat. Allow to dry.

Step four

Prime the tiki mask with one coat of Resene Quick Dry Acrylic Primer Undercoat. Allow to dry.



Step five

Paint the plinth with two coats of Resene Woodstock. Allow to dry.

Step six

Paint the tiki mask with two coats of Resene Woodstock. Allow to dry.

Step seven

Paint the mask and plinth with two coats of Resene Multishield+ Gloss. Allow to dry.

Step eight

Glue the tiki mask to the plinth with PVA glue. Allow to dry.



To get the look:

Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Havoc.



Other ideas:

Try out a green metallic effect by using Resene Isobar or Resene Obelisk.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm or www.resene.com.au/artists/artists_canvas.htm.