

★★★ Difficulty level ★easy ★★moderate ★★★challenging

Resene art with Mark Rayner – 8



It's easy to transform an old wooden filing cabinet into a sleek piece of office furniture with Resene Enamacryl Metallic.

You will need:

- Interior filler
- Old wooden filing cabinet
- Paint tray/roller
- Paintbrushes
- Resene Aquaclear semi-gloss
- Resene Enamacryl Metallic tinted to Resene Sputnik
- Resene Lumbersider tinted to Resene Cove Grey
- Resene Quick Dry Acrylic Primer Undercoat
- Resene Sandtex
- Sandpaper
- Screwdriver
- Two chrome handles



Step one

Using the screwdriver, remove the old handles from the filing cabinet. Allow to dry.



Step two

Fill any holes or imperfections in the wood using an interior filler. Allow to dry.



Step three

Lightly sand the entire filing cabinet to provide a 'key' for the paint. Allow to dry.



Step four

Apply one coat of Resene Quick Dry Acrylic Primer Undercoat. Allow to dry.



To get the look:

Mark painted the surrounding wall with Resene SpaceCote Low Sheen tinted to Resene Morning Glory.



Other ideas:

Use Resene Lustacryl tinted to Resene Nero and Resene Aquaclear gloss for a contemporary black finish.



Step five

Using an old paintbrush and 'stippling' technique, apply one coat of Resene Sandtex. Allow to dry.



Step six

Apply one coat of Resene Lumbersider Cove Grey. Allow to dry.



Step seven

Using the paint roller and tray apply two coats of Resene Enamacryl Metallic Sputnik, allowing two hours to dry between coats.



Step eight

Apply two coats of Resene Aquaclear semi-gloss, allowing two hours to dry between coats. Once dry, fit new chrome handles.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm or www.resene.com.au/artists/artists_canvas.htm.