

★★★ Difficulty level ★ easy ★★ moderate ★★★ challenging

Resene art with Mark Rayner – 9

You will need:

- 2 stainless steel hinges
- 22mm untreated plywood cut to the following dimensions: 1 @ 444mm x 800mm (base), 2 @ 45mm x 400mm (sides of lid), 2 @ 45mm x 800mm (front and back of lid), 2 @ 600mm x 400mm (side panels) and 2 @ 600mm x 800mm (front and back panels)
- 2 offcuts of timber approx 25mm x 100mm x 50mm
- 4 small castors
- 40mm brass screws
- 45mm panel pins
- 6mm hardboard cut to 444mm x 800mm (top of lid)
- Drill
- Hammer
- Interior filler
- Paintbrushes
- Piece of sash cord
- PVA glue
- Resene Enamacryl tinted to the following colours: Resene Chaos, Resene Fizz, Resene Fudge, Resene Wet N Wild
- Resene Quick Dry Acrylic Primer Undercoat
- Sandpaper
- Screwdriver

Create a fabulous teddy bear toybox using plywood and a selection of Resene colours from the Resene KidzColour range.



Step one

Using the panel pins, hammer and PVA glue, assemble the front, back, sides and base of the box.



Step two

Using the panel pins, hammer and PVA glue, assemble the front, back, sides and top of the lid. Fix the lid into position using the two stainless steel hinges and fill any holes or imperfections in the plywood using interior filler. Once the filler is dry, sand it smooth.



Step three

Drill a 10mm hole through each of the offcuts of timber and thread a length of sash through. Knot the sash at either end and glue and screw the two pieces of timber to the inside of the box and lid, as shown – this will stop the lid from falling backwards when the box is opened.



Step four

Apply one coat of Resene Quick Dry Primer Undercoat to the inside and outside of the box. Allow to dry.

To get the look:

Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Tutti Frutti and stencilled a grass motif using Resene Grass Stain and a stencil from the online Resene stencil library.



Step five

Apply two coats of Resene Chaos to the top of the lid and inside of the box. Allow to dry. Apply two coats of Resene Wet N Wild to the inside of the lid and outer sides of the box. Allow to dry.



Step six

Apply two coats of Resene Fizz to the front and back of the box. Allow to dry.



Step seven

Drill pilot holes in the base of the box and fix the four castors to the base of the box using the screwdriver.



Step eight

Paint a large paw print pattern on the front of the box using two coats of Resene Fudge. Allow to dry thoroughly before using.

Other ideas:

Use the same materials to create a more grown up storage unit, decorating the box with colours from the Resene Enamacryl Metallics range.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm or www.resene.com.au/artists/artists_canvas.htm.