

Combine Resene Crackle Effect with Resene Metallic paint to create this modern silver vase.



You will need:

- Large glass vase
- Paintbrushes (including artists' brushes)
- Resene Crackle Effect
- Resene Enamacryl Metallic tinted to Resene So Cool
- Resene testpots of Resene Alabaster (x2) and Resene Nero
- Resene Waterborne Smooth Surface Sealer
- Sandpaper
- Small paint roller and tray



Step one

Lightly sand the entire outer surface of the glass vase to provide a 'key'.



Step two

Apply one coat of Resene Waterborne Smooth Surface Sealer to the outer surface of the vase and allow to dry for two hours.



Step three

Apply one coat of Resene Alabaster to the outer surface of the vase and allow to dry for two hours.



Step four

Once dry, apply a second coat of Resene Alabaster to the vase and allow to dry for two hours.



Step five

Paint the outer surface of the vase with one coat of Resene Crackle Effect and allow to dry. Note: the thicker you apply the crackle effect, the larger the cracks will be.



Step six

Use a small paint roller and tray to apply one coat of Resene So Cool to the outer surface of the vase.



Step seven

Use an artists' brush to apply one coat of Resene So Cool around the base of the vase. Allow to dry for two hours.



Step eight

Use an artists' brush to apply one coat of Resene Nero around the rim of the vase, as shown.

To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Nebula and skirting board with Resene Enamacryl tinted to Resene Orchid White.



Other ideas:

For a bold monotone look try Resene Crackle Effect over a basecoat of Resene Nero with a topcoat of Resene Alabaster.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.co.nz or www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/artists_canvas.htm or www.resene.com.au/artists/artists_canvas.htm.