Resene

Funky drawers

Difficulty level ★easy ★★moderate ★★★challenging

Fun with furniture with Mark Rayner - 4

You will need:

- Clean cloth
- Old painted or varnished chest of drawers
- Paintbrushes (including an artists' brush)
- Resene Lustacryl semi-gloss waterborne enamel tinted to Resene Bullseye and Resene Howzat
- Resene Waterborne Smooth Surface Sealer
- Sandpaper
- Wood filler



Step one

Remove the drawers from the unit and fill any holes with wood filler. Allow to dry.



Step two

Sand the wood filler to create a smooth surface, and then sand the entire chest of drawers to provide a 'key'. Wipe off any sanding residue with a clean cloth.



Step three

Apply one coat of Resene Waterborne Smooth Surface Sealer to the main unit and allow two hours to dry.



Step four

Apply one coat of Waterborne Resene Smooth Surface Sealer to the drawer fronts and handles and allow two hours to dry.



Step five

Apply two coats of Resene Bullseye to the sides and front of the unit, allowing two hours for each coat to dry.



Apply two coats of Resene Howzat to the fronts of each drawer, allowing two hours for each coat to dry.



Step seven

Apply two coats of Resene Howzat to the top and base of the unit, allowing two hours for each coat to dry.



Step eight

Apply two coats of Resene Bullseye to the handles on each drawer, allowing two hours for each coat to dry.





To get the look:

painted the Mark background wall with Resene SpaceCote Flat tinted to Resene Zeal.



Other ideas:

Create another vibrant cool/hot combination using Resene Balloon and Resene Resolution Blue.

For more ideas inspiration visit your local Resene ColorShop www.resene.co.nz www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/ artists canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.



