

★★★ Difficulty level ★easy ★★moderate ★★★challenging

Ways with wood,
with Mark Rayner – 6

Exterior

Turn a humble kitset potting bench into a stylish garden feature with the help of Resene Woodsman oil stain.

You will need:

- Kitset potting bench
- Paintbrush
- Pencil
- PVA exterior glue
- Resene Woodsman penetrating oil stain tinted to Resene Zydeco

- Screwdriver
- Set square
- Tape measure
- Turps for washing brush



Step one

Following manufacturer's instructions, run a thin line of PVA along the grooves in the back and side panels of the potting bench and attach to the plywood top, fixing with the screws provided.



Step two

Fix the side panels to the front panel with PVA glue and screws, as shown.



Step three

Fix the legs to the potting bench with PVA glue and screws – use the set square to make sure they're at right angles.



Step four

Use the tape measure and set square to rule a line 175mm from the bottom of each leg, as shown.



Step five

Fix the two side leg struts with PVA and screws, aligning the bottom edge of each strut with the pencil line.



Step six

Fix the bottom shelf to the side leg struts with PVA and screws, as shown.



Step seven

Carefully apply one coat of Resene Zydeco to the potting bench and leave to dry for 24 hours.



Step eight

Apply a second coat of Resene Zydeco. Leave to dry for a further 24 hours before using the potting bench.



To get the look:

Mark stained the background shed wall with Resene Waterborne Woodsman tinted to Resene Smokey Ash – see Ways with wood project #1 for further information.



Other ideas:

For a more natural effect try using Resene Woodsman tinted to Resene Driftwood or Resene Pickled Bean.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.

In Australia:

Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand:

Call 0800 RESENE, visit www.resene.co.nz
or email advice@resene.co.nz