



Difficulty level ★easy ★★moderate ★★★challenging

Ways with wood,
with Mark Rayner – 15

Exterior

You will need:

- DIY kitset wooden bird feeder
- Exterior PVA glue
- Hammer
- Paintbrush

- Resene testpots of Resene Waterborne Woodsman penetrating oil stain in the following colours: Resene Bamboo, Resene Rangitoto and Resene Totem Pole



Step one
Assemble the sides and base of the bird feeder, fixing with nails provided and exterior PVA glue.



Step two
Assemble the front and back panels of the bird feeder, as shown.



Step three
Paint the inside of the birdfeeder with one coat of Resene Rangitoto.



Step four
Paint the underside of the roof panels with one coat of Resene Rangitoto. Leave to dry for 24 hours and apply a second coat of Resene Rangitoto.



Step five
Once touch dry, assemble the roof panels, as shown.



Step six
Paint the sides of the bird feeder with one coat of Resene Bamboo.



Step seven
Paint the underside, front and back panels of the bird feeder with one coat of Resene Bamboo.



Step eight
Paint the roof panels with one coat of Resene Totem Pole. Leave to dry for 24 hours and apply a second coat of Resene Bamboo and Resene Totem Pole. Allow 24 hours to dry before positioning birdfeeder outside in the garden.

Use a few testpots of Resene Waterborne Woodsman to transform a kitset wooden birdfeeder from drab to fab.



To get the look:

Mark fixed the bird feeder onto an old weathered fence post with exterior construction glue.



Other ideas:

To make the bird feeder blend into the surrounding garden, stain it with a natural brown Resene Waterborne Woodsman stain such as Resene Dark Oak or Resene English Walnut.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.

In Australia:

Call 1800 738 383, visit www.resene.com.au or email advice@resene.com.au

In New Zealand:

Call 0800 RESENE, visit www.resene.co.nz or email advice@resene.co.nz