



★★★ Difficulty level ★ easy ★★ moderate ★★★ challenging

Ways with wood
with Mark Rayner – 96

You will need:

- Clean cloths
- Old wooden photo frame
- Paint stirrers
- Paintbrushes
- Resene Aquaclear Natural Flat
- Resene Colorwood tinted to Resene Dark Oak
- Rubber gloves
- Sandpaper (medium and fine)



Step 1
Remove any paper tape, glass and old hanging devices from the back of the photo frame.



Step 2
Sand the photo frame with medium sandpaper. Once back to bare wood, finish off with fine sandpaper.



Step 3
Wipe off any sanding residue with a clean cloth.



Step 4
Carefully stir the Resene Colorwood tinted to Resene Dark Oak.



Step 5
Apply one coat of Resene Colorwood tinted to Resene Dark Oak to the photo frame. Allow the stain to penetrate the wood for a few minutes.



Step 6
Wearing rubber gloves, wipe off any excess Resene Colorwood tinted to Resene Dark Oak and allow to dry.



Step 7
Carefully stir the Resene Aquaclear Natural Flat.



Step 8
Apply three coats of Resene Aquaclear Natural Flat to the photo frame allowing two hours for each coat to dry.

Interior

Use Resene Colorwood and Resene Aquaclear to restore an old wooden photo frame to its former glory.



To get the look: Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Alabaster.



Other ideas:
For a reddish brown effect use Resene Colorwood tinted to Resene Japanese Maple.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/colorshops.

Check out more project ideas online www.resene.com/projects.