





Difficulty level ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 10

You will need:

- 20mm plywood or MDF cut to the following dimensions: 70mm x 350mm (x3) 70mm x 300mm (x2)
- 25mm nails

- 40mm panel pins
- Hammer
- **Paintbrush**
- Panel pins
- PVA glue
- Pencil
- Resene Enamacryl tinted
 Set square to Resene Daredevil
- Resene paint stirrers (x2)
- Resene Quick Dry
- Saw
- Sandpaper
- Screwdriver
- Screws

 - Tape measure



Build this mini mug shelf in a few hours

and use two Resene paint stirrers to form

hanging

a handy

Top tip:

Mark painted the background wall with Resene SpaceCote Low Sheen tinted to Resene Bowie.



Step one

Measure and mark the plywood or MDF to the dimensions listed above.



Step two

Cut the pieces of plywood or MDF to size using a sharp saw.



Step three

Smooth any rough edges with sandpaper.



Step four

Attach pieces together, as shown, using panel pins and PVA glue. Use a set square to ensure corners are at right angles.



Step five

Fix two paint stirrers to the back of the shelf unit, as shown, using 25mm nails and PVA glue. Allow the glue to dry.



Step six

Apply one coat of Resene Quick Dry to the shelf unit and allow two hours to dry.



Step seven

Apply two coats of Resene Daredevil to the shelf unit, allowing two hours for each coat to dry.



Step eight

Attach the shelf unit to a wall, fixing small screws through the hole of each paint stirrer, as shown.



Other ideas:

Create a kitchen herb rack in the same way and finish off with Resene Enamacryl tinted to Resene Kea.

ideas more and inspiration visit your local Resene ColorShop or www.resene.co.nz www.resene.com.au.

Check out our special Artists section online www.resene.co.nz/artists/ artists canvas.htm

www.resene.com.au/ artists/artists_canvas.htm.

