# Resene

## Stencilled house no.



**Difficulty level** ★easy ★★moderate ★★★challenging

Weekend DIY with Mark Rayner - 57

#### You will need:

- Circular piece of wood (we used a small chopping board)
- Craft knife
- Damp cloth
- Low tack masking tape
- Paintbrushes

- Print out of house number
- Resene Quick Dry
- Resene testpots of Resene Aquamarine and Resene Sea Nymph
- Sandpaper



Step one

Lightly sand the piece of wood rubbing in the direction of the grain.



Step two

Wipe off any sanding residue with a damp cloth and allow to dry.



Step three

Apply one coat of Resene Quick Dry to the piece of wood (front and back) and allow to dry.



#### Step four

Apply one coat of Resene Sea Nymph to the piece of wood (front and back) and allow to dry.



Step five

Apply a second coat of Resene Sea Nymph to the piece of wood (front and back) and allow to dry.



Step six

Using the craft knife, carefully cut out the house number to create a stencil.



### Step seven

Attach the stencil to the piece of wood with low tack masking tape.



#### Step eight

Using a dry brush, carefully stipple Resene Aquamarine over the stencil. Carefully remove the stencil and allow the paint to dry.





### To get the look:

Mark painted the background wall with Resene Lumbersider tinted to Resene Fringy Flower.



#### Other ideas:

For a bold orange and blue contrast, stipple Resene Elvis over a basecoat of Resene Adrenalin.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.



