

Fan trellis

Difficulty level ★easy ★★moderate ★★★challenging

the state of the s

Ways with wood with Mark Rayner – 66

You will need:

- 40mm galvanised nails
- Clean cloth
- Hammer
- Mineral turpentine
- Paintbrush

- Resene paint pot
- Paint stirrer
- Resene Woodsman Wood Oil Stain tinted to Resene Earthsong
- Sandpaper

ing philipping the control of the co



Step oneRemove any labels from the fan trellis



Step twoSmooth any rough edges with sandpaper and wipe off any sanding residue with a clean cloth.



Step threeCarefully stir the Resene
Woodsman Wood Oil
Stain.



Step four
Apply one coat of Resene
Woodsman Wood Oil
Stain to the back of the
trellis. Once touch dry,
turn over and apply one
coat to the front of the
trellis.



Step five
Continue until the entire
piece of trellis is covered
in Resene Woodsman
Wood Oil Stain. Allow 24
hours to dry.



Step six
Apply a second coat of
Resene Woodsman Wood
Oil Stain to the front and
back of the trellis. Again,
allow 24 hours to dry.



Step sevenWash brush in mineral turpentine.



Step eightFix trellis to fence using galvanised nails.

Exterior

Transform a plain fan trellis into an attractive garden feature using Resene Woodsman Wood Oil Stain.



To get the look:

Mark painted the background fence with Resene Lumbersider tinted to Resene Eternity.



Other ideas:

For a strong contrasting effect stain the trellis with Resene Woodsman tinted to Resene Pitch Black and attach to a fence or wall painted with Resene Alabaster.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/ colorshops.

Check out more project ideas online www.resene.com/projects.