

under the sea



STEP-BY-STEP

STEP 1: Remove the drawers and drawer handles and fill the holes with interior filler. Allow to dry and lightly sand all surfaces.



STEP 2: Apply one coat of Resene Smooth Surface Sealer to the drawers. Allow to dry.

STEP 3: Apply two coats of Resene Resolution Blue to the drawers. Allow to dry. Replace the drawers and paint a band of two coats of Resene Corvette along the bottom for a sandy seabed.



STEP 4: With an artist's brush, paint a coral formation using Resene West Side, seaweed using Resene Grass Stain and another cluster of coral using Resene Havoc. Allow to dry.

STEP 5: With a 4mm drill bit, drill and fix handles into position with screws and a generous blob of construction glue.



*The base paint for this project was Resene Lustacryl tinted to the various colours used.

TIP: If you can't find fish handles, make your own using MDF and a jigsaw. Don't forget they'll need priming which you can do with Resene Quick Dry primer undercoat.

Breathe new life into an old set of drawers with colours and creatures from the ocean.

hang it...

For easy-to-make hooks for your child's bedroom, download these stencils (with plenty more to choose from) from www.resene.co.nz/kids/kids_stencils.htm

* Projects designed by Mark Rayner.
For products used for these designs, see 'Under the Sea' on www.littlies.co.nz under Littlies Activities/Resene.



the paint the professionals use
0800 RESENE (737 363) www.resene.co.nz