

Resene WashWISE Mini

How to use

Step 1: Add 100ml of Cloudy Ammonia and stir aggressively.

Step 2: Add 100ml of Resene WashWise Flocculent and stir aggressively.

Step 3: Check for separation. This should be visible after 30 minutes. Add an extra 50ml of Resene WashWise Flocculent and stir if no change noticed.

Step 4: Leave overnight.

Step 5: Attach the waste pipe to the outlet tap and direct the other end to sewerage, a flat surface or lawn away from stormwater drains or natural water sources, or to a waste container.

Step 6: Open the tap and run off the clear/thin coloured waste water. This is a mixture of water, colourants, and other liquid parts of paint. Do not release to stormwater systems.

Step 7: Remove the paint sludge. This can be mixed with a small scoop of Resene Washwise Crystals to make it solid or left to dry, then disposed of through your normal rubbish service.



WashWise

www.resene.com/washwise