

DECK CLEAN

YOU WILL NEED: Broom, bucket, hose with running water, stiff-bristled brush, timber-cleaning agent (we used Resene Timber and Deck Wash)



STEP ONE

Sweep the deck clean of any dry dirt and debris.



STEP TWO

Dilute the timber-cleaning agent with fresh water, following the manufacturer's recommendations. Thoroughly scrub the soapy solution into the decking.



STEP THREE

Allow the wood to remain wet for around 15 minutes and then rinse thoroughly with clean water. Allow to dry.

DECK REPAIR

YOU WILL NEED: 75mm galvanised decking nails, crowbar (or similar) for removing damaged plank, hammer, paintbrush, pencil, ruler, sandpaper, saw, wood stain (to match the rest of deck), new piece of decking (to match original)



STEP ONE

Using the hammer and crowbar, remove the broken decking plank, lifting from one end. Take care not to damage the adjoining planks.



STEP FOUR

Apply two coats of wood stain to the new plank, following the manufacturer's recommendations. Allow to dry.



STEP TWO

Measure and mark the new piece of decking to fit, using the back of the saw to rule an accurate 90-degree cutting line across the plank.



STEP FIVE

Fix the new plank into position with 75mm deck nails.



STEP THREE

Cut the piece of decking using the pencil line as a guide and smooth the cut edge with sandpaper.

TOP TIP

Though the newly stained plank will look darker for a while, it will eventually weather to the same colour as the rest of the deck, but if you want an instant match, simply give the rest of the deck a freshen up with one coat of deck stain.