

DANGER

KEEP OUT OF REACH OF CHILDREN

Resene

Timber and Deck Wash

exterior

**net contents
1 litre**

LL846960TF 1/13

WARNING

Read label before use. Keep out of reach of children. May cause corrosion to metals. Causes severe skin burns and serious eye damage.

PRECAUTIONS

DO NOT BREATHE FUMES/MISTS/SPRAYS/VAPOURS. USE WITH ADEQUATE VENTILATION. DO NOT EAT, DRINK OR SMOKE WHILE USING.

Store in original or correctly labelled container, tightly closed, in a well ventilated area indoors, away from foodstuffs, either between 15°C-20°C or at a cool, constant temperature. Store locked up. Store only in original container. Wash thoroughly after handling. Wear protective gloves/clothing and eye/face protection. Dispose of empty container safely. Consult Resene checklist on environmentally acceptable methods for cleaning equipment and disposing of unwanted paint.

FIRST AID

IF SWALLOWED: Do NOT induce vomiting. Rinse mouth.

IF ON SKIN (or hair): Remove/take off immediately all contaminated clothing and wash before re-use. Rinse skin with water/shower.

EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing.

INHALATION: Remove to fresh air and keep at rest in a position comfortable for breathing. IF BREATHING DIFFICULT GET MEDICAL ATTENTION IMMEDIATELY.

When seeking medical advice take this container with you.

Further information can be obtained from AUST: POISONS INFORMATION CENTRE 131 126 or call Resene 1800 738 383.

NZ: NATIONAL POISONS CENTRE 0800 POISON (764 766)

or call Resene 0800 737 363.

For use as a timber wash.

CONTAINS: Sodium metasilicate 25-30 gms/L.

CAUTION

• Do not add Resene Timber and Deck Wash to paint.

• Thoroughly clean spray equipment with freshwater immediately after use. Do not store concentrated or diluted product in metal or aluminium containers.

• Do not allow the product to come into contact with plants, stormwater outlets, streams or animals. Harmful to aquatic life with long lasting effects. Divert all run-off to a sewer or alternative catchment system.

• Store locked up.

• Wear protective gloves, clothing, eye and face protection. Wash thoroughly after handling.

Resene Timber and Deck Wash is a quick and easy way to clean surfaces, such as weatherboards and decks, prior to staining or painting.

Preparation

• This product may be used to clean a wide variety of surfaces. If the surface you propose to clean is not referred to, try a small test area first or contact your local Resene ColorShop or Reseller for advice.

Application

• Wear adequate protection. Use overalls, gloves, eye protection and suitable footwear.

• Mix with water and apply to saturate the surface. Keep the surface wet for 10-15 minutes. Do not use when the area to be cleaned is in direct sun.

• Scrub vigorously using a stiff nylon bristle broom or hard bristle scrubbing brush to loosen contaminants then wash off with copious quantities of freshwater.

• For best results, use high pressure washing (60-80 bar pressure). Do not use high pressure waterblasting as it will damage the timber surface. Always clean from the highest point down and if high pressure washing use a soft even fan-shaped water jet. Do not use turbo heads. Scrubbing during low pressure washing (garden hose) will be required to remove surface contaminants.

• Ensure product is well rinsed off glass surfaces. Concentrated product left on glass surfaces may etch the surface.

• If heavy mould or moss deposits are present, treat the surface with Resene Moss & Mould Killer (see Data Sheet D80) prior to using Resene Timber and Deck Wash.

Please ensure that use of this product is compatible with the substrate and surface preparation method. Resene does not accept any responsibility for the application of incorrect product to substrate. For further painting advice and information, call 1800 738 383 (AUST), 0800 737 363 (NZ) or visit the Resene website.

Quick check

Use on: New or weathered timber.

Appearance: Pale orange.

Mixing ratio: One part Resene Timber and Deck Wash to three parts freshwater for weathered timber; or one part to six parts for new timber.

Usage (diluted mix): 10 square metres per litre per coat.


Number of applications: One.

Application method: Watering can or low pressure spray. Sufficient material must be applied to maintain wetness of the surface for 10-15 minutes.

Thinning and clean up: Water.

Enjoy the Resene Promise of quality on premium paints. See your Resene ColorShop or the Resene website for a copy.

In every case it is recommended that the appropriate Data Sheet and Safety Data Sheet are consulted prior to application.



Timber and Deck Wash SDS



Timber and Deck Wash TDS



In Australia:

Resene Paints (Aust) Limited

7 Production Ave, PO Box 924, Beenleigh, Qld 4207

Phone 1800 738 383 Fax 1800 064 960

Email advice@resene.com.au or visit www.resene.com.au

Resene

the paint the professionals use

In New Zealand:

Resene Paints Ltd

Vogel Street, PO Box 38242, Wgtn Mail Centre, Lower Hutt 5045

Phone 04 577 0500 Fax 04 577 0600

Email advice@resene.co.nz or visit www.resene.co.nz

DANGER

KEEP OUT OF REACH OF CHILDREN

Resene

Timber and Deck Wash

exterior

net contents 4 litres

WARNING

Read label before use. Keep out of reach of children. Causes skin irritation. Causes severe eye damage.

PRECAUTIONS

DO NOT BREATHE MISTS/SPRAYS/VAPOURS. USE WITH ADEQUATE VENTILATION. DO NOT EAT, DRINK OR SMOKE WHILE USING.

Store in original or correctly labelled container, tightly closed, in a well ventilated area indoors, away from foodstuffs, either between 15°C-20°C or at a cool, constant temperature. Wear protective gloves/clothing and eye/face protection. Wash thoroughly after handling. Dispose of empty container safely. Consult Resene checklist on environmentally acceptable methods for cleaning equipment and disposing of unwanted paint. Do not contaminate any water supply. Absorb spillage to prevent material damage.

FIRST AID

IF SWALLOWED: Do NOT induce vomiting. Rinse mouth.

IF ON SKIN (or hair): Remove/take off immediately all contaminated clothing and wash before re-use. Rinse skin with water/shower.

EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do so. Continue rinsing.

INHALATION: Remove to fresh air and keep at rest in a position comfortable for breathing. IF BREATHING DIFFICULT GET MEDICAL ATTENTION IMMEDIATELY. When seeking medical advice take this container with you.

Further information can be obtained from AUST: POISONS INFORMATION CENTRE 131 126 or call Resene 1800 738 383.

NZ: NATIONAL POISONS CENTRE 0800 POISON (764 766) or call Resene 0800 737 363.

For use as a timber wash.

CONTAINS: Sodium metasilicate 10-100 gms/L.

CAUTION

- Do not add Resene Timber and Deck Wash to paint.
- Thoroughly clean spray equipment with freshwater immediately after use. Do not store concentrated or diluted product in metal or aluminium containers.
- Do not allow the product to come into contact with plants, stormwater outlets, streams or animals. Harmful to aquatic life with long lasting effects. Divert all roof run-off to a sewer or alternative catchment system.
- Store locked up.
- Wear protective gloves, clothing, eye and face protection. Wash thoroughly after handling.

In Australia:

Resene Paints (Aust) Limited
7 Production Ave, PO Box 785, Ashmore City, Queensland, 4214
Phone 1800 738 383 Fax 1800 064 960
Email advice@resene.com.au or visit www.resene.co.nz

Resene Timber and Deck Wash is a quick and easy way to clean surfaces, such as weatherboards and decks, prior to staining or painting.

Preparation

- This product may be used to clean a wide variety of surfaces. If the surface you propose to clean is not referred to, try a small test area first or contact your local Resene ColorShop or Reseller for advice.

Application

- Wear adequate protection. Use overalls, gloves, eye protection and suitable footwear.
- Mix with water and apply to saturate the surface. Keep the surface wet for 10-15 minutes. Do not use when the area to be cleaned is in direct sun.
- Scrub vigorously using a stiff nylon bristle broom or hard bristle scrubbing brush to loosen contaminants then wash off with copious quantities of freshwater.
- For best results, use high pressure washing (60-80 bar pressure). Do not use high pressure waterblasting as it will damage the timber surface. Always clean from the highest point down and if high pressure washing use a soft even fan-shaped water jet. Do not use turbo heads. Scrubbing during low pressure washing (garden hose) will be required to remove surface contaminants.
- Ensure product is well rinsed off glass surfaces. Concentrated product left on glass surfaces may etch the surface.
- If heavy mould or moss deposits are present, treat the surface with Resene Moss & Mould Killer (see Data Sheet D80) prior to using Resene Timber and Deck Wash.

Quick check

Use on: New or weathered timber.

Appearance: Pale orange.

Mixing ratio: One part Resene Timber and Deck Wash to three parts freshwater for weathered timber; or one part to six parts for new timber.

Usage (diluted mix): 10 square metres per litre per coat.

Number of applications: One.

Application method: Watering can or low pressure spray. Sufficient material must be applied to maintain wetness of the surface for 10-15 minutes.

Thinning and clean up: Water.



Enjoy the Resene Promise of quality on premium paints. See your Resene ColorShop or the Resene website for a copy.

In every case it is recommended that the appropriate Data Sheet and Safety Data Sheet are consulted prior to application.

For further painting advice and information, call 1800 738 383 (AUST), 0800 RESENE (NZ) or visit the Resene website.

**In New Zealand:**

Resene Paints Ltd
Vogel Street, PO Box 38242, Wgtn Mail Centre, Lower Hutt 5045
Phone 04 577 0500 Fax 04 577 0600
Email advice@resene.co.nz or visit www.resene.co.nz

Resene

the paint the professionals use