

★★★ Difficulty level ★ easy ★★ moderate ★★★ challenging

Ways with wood,
with Mark Rayner – 8

Enjoy the outdoors, and create a simple garden bench with treated timber and Resene Woodsman penetrating oil stain.

You will need:

- 50mm x 50mm treated timber cut to the following lengths: 4 x 360mm, 4 x 400mm, 8 x 900mm
- 2 pieces of 9mm treated plywood measuring 100mm x 900mm
- 2 small right angle triangles cut from 9mm plywood
- 40mm galvanised nails
- 75mm galvanised nails
- 100mm galvanised nails
- Circular saw
- Drill with 4mm drill bit
- Hammer
- Paintbrush
- Pencil
- PVA exterior glue
- Resene Woodsman penetrating oil stain tinted to Resene Japanese Maple
- Sandpaper
- Set square
- Tape measure
- Turps for washing brush



Step one

Using the circular saw, cut timber to the lengths listed above – use the set square and pencil to ensure cuts are made at right angles.



Step two

Form two identical wooden squares from the 400mm and 360mm lengths of timber, as shown. Fix together with PVA glue and a 100mm nail at each corner (drill a pilot hole first to prevent the wood from splitting).



Step three

Stand the two squares upright and fix a 900mm length of timber between, forming the back edge of the seat. Use PVA and 40mm nails through the plywood triangles to fix in position – use the set square to ensure the legs are at ninety degrees.



Step four

Cut the remainder of the plywood to the dimensions listed above and smooth any rough edges with sandpaper.



Step five

Fix one of the plywood strips to front of the bench, as shown, using PVA and 40mm nails.



Step six

Fix the second plywood strip, in the same way, about halfway down the back of the bench, as shown.



Step seven

Carefully apply one coat of Resene Japanese Maple to the entire bench frame and remaining 900mm timber lengths. Leave to dry for 24 hours and apply a second coat to all – leave for a further 24 hours to dry.



Step eight

Working from the back, fix the remaining timber lengths into position to form the seat using 75mm nails and PVA glue – use an off-cut of plywood to ensure the lengths are evenly spaced. Leave overnight for the glue to fully dry before using.



To get the look:

Mark planted the surrounding area of garden with a selection of easy-care daisies, lavender and small succulents.



Other ideas:

For a vibrant green effect try using Resene Woodsman tinted to Resene Zydco.

For more ideas and inspiration visit your local Resene ColorShop or the Resene website.