

★★★ Difficulty level ★ easy ★★ moderate ★★★ challenging

Weekend DIY with Mark Rayner – 39

Transform an old wooden drawer into a stylish shelf with a little bit of help from Resene.

You will need:

- Clean cloth
- Fittings to hang shelf
- Hammer
- Old wooden drawer
- Paintbrush
- Panel pins
- Pencil
- Pieces of MDF
- Putty knife or similar
- PVA glue
- Resene Lustacryl tinted to Resene Half Sea Fog
- Resene Quick Dry
- Resene SpaceCote Flat tinted to Resene Paua
- Sandpaper
- Saw
- Screwdriver
- Tape measure
- Wood filler




Step one

Carefully remove any damaged pieces of wood from the drawer and remove handle.



Step two

Measure, mark and cut pieces of MDF to replace the damaged pieces of wood. Sand smooth any rough edges.



Step three

Fix the pieces of MDF into position using panel pins and PVA glue. Allow glue to dry.



Step four

Fill any holes with wood filler and allow to dry.



Step five

Lightly sand the shelf unit and wipe off any sanding residue with a clean cloth.



Step six

Apply one coat of Resene Quick Dry to the shelf unit and allow two hours to dry.



Step seven

Apply two coats of Resene Half Sea Fog to the inner and outer sides of the shelf unit, allowing two hours for each coat to dry.



Step eight

Apply two coats of Resene Paua to the back of the shelf unit, allowing two hours for each coat to dry. Attach fittings to hang shelf.



To get the look:

Mark painted the background wall with Resene SpaceCote Flat tinted to Resene Paua.



Other ideas:

For a rich theatrical look paint the sides of the shelf with Resene All Black and the back and background wall with Resene Pohutukawa.

For more ideas and inspiration visit your local Resene ColorShop or www.resene.com/colorshops.

Check out more project ideas online www.resene.com/projects.