

Resene Ceiling Velvet flat enamel

Resene Ceiling Velvet dries to a beautiful, even, flat finish ideal for ceilings in dry and wet areas. Based on a tough solventborne resin to give fast drying and durability in all hardwearing areas. This lower odour formulation is easy to apply and dries without the unwanted and strong solvent odours associated with traditional solventborne products.

interior

Typical uses

- Ceilings especially in wet areas, such as
- Bathrooms
- Kitchens
- Laundries

Vehicle type	Alkyd
Pigmentation	Titanium dioxide
Solvent	Low odour hydrocarbon, less than 1% aromatic hydrocarbon content
Finish	Flat
Colour	White and colours off white
Dry time (minimum)	6 hours at 18°C
Recoat time (minimum)	16 hours
Primer required	Yes
Theoretical coverage	12-14 sq. metres per litre
Dry film thickness	34 microns at 14 sq. metres per litre
Usual no. of coats	2
Abrasion resistance	Good
Chemical resistance	Fair
Heat resistance	Good
Solvent resistance	Fair
Thinning	Resene Thinner No.2 (lower odour) or Mineral turps (brush/roller); Resene Thinner No.9 (spray)
Clean up	Resene Thinner No.2, Mineral turps or Resene Brush Cleaner (brush/roller); Resene Thinner No.9 (spray)
VOC	c. 410 grams per litre (see Resene VOC Summary)

Physical properties

Performance

Performance and limitations

1. Excellent for wet areas where a durable and attractive finish is required as it does not exhibit surfactant leaching.
2. Excellent flow for a smooth, even flat finish.
3. Easy to clean or wash surface.
4. Lower odour formulation than traditional enamels, less than 1% aromatic hydrocarbon content.
5. May be applied over a wide range of temperatures.

Limitations

1. **Not for exterior use.**
2. Ensure the correct primer or sealer is used.
3. Not for use as first coat on fibre or particle board, use Resene Quick Dry (see [Data Sheet D45](#)) on particle board. On fibre cement board use Resene Sureseal (see [Data Sheet D42](#)).
4. Not for use as the first coat on hardboard, use Resene Sureseal (see [Data Sheet D42](#)).
5. Not suitable for direct application to cementitious surfaces, use Resene Sureseal (see [Data Sheet D42](#)).
6. Drying may be affected by low temperatures and high humidity.
7. May yellow in dark areas.

Ceiling Velvet flat enamel

Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould.

If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)). Sand to smooth finish and dust off. Old enamels require sanding to a uniform dull finish.

Prime as per the following:

Particle board

Resene Quick Dry (see [Data Sheet D45](#)).

Plasterboard

Plasterboard and stoppings in non wet areas should be primed (e.g. Resene Broadwall Waterborne Wallboard Sealer - see [Data Sheet D403](#)). Fibrous plaster or plasterboard and stoppings in wet areas should be sealed with Resene Sureseal ([Data Sheet D42](#)). Resene Sureseal (see [Data Sheet D42](#)) must be used where plasterboard has yellowed due to prolonged exposure to sunlight.

Timber (Matai, Spotted Gum, Totara)

Resene Quick Dry (see [Data Sheet D45](#)).

Timber (all other timbers)

Resene Quick Dry (see [Data Sheet D45](#)) or Resene Enamel Undercoat (see [Data Sheet D44](#)).

Varnished surfaces, laminated surfaces

Resene Waterborne Smooth Surface Sealer (see [Data Sheet D47a](#)).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Apply by brush, Resene No.5 roller sleeve or spray.

- **New** - Prepare and prime as above. Apply one coat of Resene Enamel Undercoat (see [Data Sheet D44](#)) in required colour or Resene Quick Dry (see [Data Sheet D45](#)). Allow to dry then sand lightly. Dust off. Apply one to two coats of Resene Ceiling Velvet in required colour. Some bright colours may require an additional coat.
- **Repaint** - Prepare surface and spot prime as above. Thoroughly sand any existing solventborne enamel paint finish to ensure adhesion of subsequent coats. Apply one coat of Resene Enamel Undercoat (see [Data Sheet D44](#)) in required colour or Resene Quick Dry (see [Data Sheet D45](#)). Allow to dry then sand lightly. Dust off. Apply one to two coats of Resene Ceiling Velvet in required colour. If applying over existing Resene Ceiling Velvet, then use two coats of Resene Ceiling Velvet in required colour directly over the existing paint finish. Some bright colours may require an additional coat.

Precautions

1. **While this product is formulated using low odour solvents, you must ensure there is good ventilation during application and curing. Avoid breathing vapour.**
2. Ensure correct primer and/or sealer is used.
3. Fill all nailholes and cracked timber after priming.
4. **FLAMMABLE** - Keep away from heat and open flame. Keep closed when not in use.



Ceiling Velvet SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.