# D310

# Resene Lustacryl semi-gloss

waterborne enamel

Resene Lustacryl is the result of long, careful, intensive research. This breakthrough product may be used in all those areas traditionally reserved for solventborne enamels. Nonyellowing and fast drying with easy water clean up.

# exterior/interior

# Typical uses

- Architraves
- Bathrooms
- Furniture
- Kitchens
- Laundries
- Plywood
- Skirtings
- Timber doors
- Wallboards
- Window frames

	<i>y</i> 1 1
Vehicle type	New generation acrylic
Pigmentation	Titanium dioxide
Solvent	Water
Finish	Semi-gloss
Colour	Selected Resene Tota
	BS5252, Multi-Finish, \
	Range
Dry time (minimum)	45 minutes at 18°C
Recoat time (minimum)	2 hours
Serviceable within	12-48 hours dependin
٤	levels and drying condit
Primer required	Yes

Theoretical coverage Dry film thickness Usual no. of coats Abrasion resistance Chemical resistance Heat resistance Solvent resistance Durability Thinning and clean up Semi-gloss Selected Resene Total Colour System, including 3S5252, Multi-Finish, Whites & Neutrals and The Range 45 minutes at 18°C 2 hours 12-48 hours depending on film thickness, tinter

**Physical properties** 

' levels and drying conditions
yired Yes
12 sq. metres per litre
34 microns at 12 sq. metres per litre
2; some colours may require an additional coat
very good
ance Fair
ance Good
bility Excellent
in up Water; in hot dry conditions may be thinned with up to 5% Resene Hot Weather Additive
VOC c. 63 grams per litre (see Resene VOC Summary)

# **Performance and limitations**

#### Performance

- May be used wherever solventborne enamels have traditionally been used.
- 2. Non-yellowing.
- Resene Lustacryl may be applied over Resene Quick Dry waterborne primer undercoat (see Data Sheet D45) or directly over sound, clean old enamel surfaces.
- 4. Clean, spatter free application.
- 5. An Environmental Choice approved product.
- **Limitations** 1. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
  - 2. Ensure the correct primers and/or sealers are used.
  - 3. Due to waxes used in fibre and particle board it is essential that Resene Quick Dry (see Data Sheet D45) is used as the first coat.



# Lustacryl semi-gloss waterborne enamel

### Surface preparation

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease and mould.

If moss and mould are present, treat with Resene Moss & Mould Killer (see Data Sheet D80). Sand to smooth finish and dust off. Old enamels require fine sanding to a uniform dull finish.

### Prime as per the following:

#### Cedar, weathered timber

Treat with Resene TimberLock (see Data Sheet D48). Prime with Resene Quick Dry (see Data Sheet D45). (Where a staining type of timber exists an application of Resene Wood Primer (see Data Sheet D40) may be required).

#### Fibrous plaster, paperfaced plasterboard

Resene Broadwall Waterborne Wallboard Sealer (see Data Sheet D403). Ensure new paperfaced plasterboard is prepared to a level of finish suitable for the specified paint finish. Resene Broadwall Surface Prep & Seal (see Data Sheet D807) or Resene Broadwall 3 in 1 (see Data Sheet D810) will be required to achieve a level 5 finish.

#### Particle board, timber

Resene Quick Dry (see Data Sheet D45). (Where a staining type of timber exists an application of Resene Wood Primer (see Data Sheet D40) may be required).

#### Laminated surfaces, varnished surfaces

Resene Waterborne Smooth Surface Sealer (see Data Sheet D47a).

#### Soft or absorbent surfaces

Where the surface to be painted is considered too soft to form a stable substrate, a saturation coat of a fully penetrating sealer, such as Resene Sureseal (see Data Sheet D42), may be required.

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

# Application

Apply by brush, speed brush, synthetic fibre roller or spray. In hot dry conditions thin with up to 5% Resene Hot Weather Additive.

#### New

- 1. Prepare and prime as above.
- Apply two coats of Resene Lustacryl in required colour allowing at least two hours between coats. 2.

#### Repaint

- 1. Prepare surface and spot prime as above.
- 2. Apply two coats of Resene Lustacryl in required colour allowing at least two hours between coats.

# **Precautions**

- 1. Ensure the correct primer and/or sealer is used.
- 2. Stop all nailholes and cracked timber after priming.
- 3. Allow putty to thoroughly harden before painting.
- 4. Allow Resene Lustacryl sufficient drying before putting into full service.
- 5. Serviceable within 12-48 hours depending on film thickness, tinter level and drying conditions.



Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.



Call 1800 738 383, visit www.resene.com.au

or email advice@resene.com.au



#### In New Zealand

PO Box 38242, Wellington Mail Centre, Lower Hutt 5045 Call 0800 RESENE (737 363), visit www.resene.co.nz the paint the professionals use or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle