

# Resene Wintergrade Quick Dry

low temperature  
curing waterborne  
primer undercoat

Resene Wintergrade Quick Dry is designed to cure at low temperatures down to 2°C. It provides long term flexibility over unstable substrates coupled with exceptional durability even when left uncoated for prolonged periods.

**exterior/interior**

## Typical uses

- Architraves
- Block and brickwork
- Cement plaster
- HDF and MDF
- Cloth and woven wallcoverings
- Fibre and particle board
- Repaint old work
- Timber (including Matai, Spotted Gum, Totara)
- Wallboards
- Wallpaper

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at [www.resene.com/datasheets](http://www.resene.com/datasheets). If in doubt contact Resene.

<b>Vehicle type</b>	100% acrylic
<b>Pigmentation</b>	Titanium dioxide/fillers
<b>Solvent</b>	Water
<b>Finish</b>	Low sheen
<b>Colour</b>	White
<b>Dry time (minimum)</b>	Dependent on weather conditions
<b>Recoat time (minimum)</b>	4 hours; recoat when first coat is tough enough to resist the pressure of a firmly pressed, twisted thumb
<b>Sealer required</b>	See precautions
<b>Theoretical coverage</b>	12.5 sq. metres per litre
<b>Dry film thickness</b>	35 microns at 12.5 sq. metres per litre
<b>Usual no. of coats</b>	1-2
<b>Chemical resistance</b>	Good
<b>Heat resistance</b>	Thermoplastic
<b>Solvent resistance</b>	Good
<b>Sanding properties</b>	Good
<b>Durability</b>	Excellent
<b>Thinning and clean up</b>	Water
<b>VOC</b>	c. 19 grams per litre (see <a href="#">Resene VOC Summary</a> )

## Physical properties

## Performance

## Performance and limitations

1. Will cure at low temperatures.
2. Excellent adhesion to substrates including old paint.
3. Outstanding durability maintaining flexibility for the life of the system.
4. Excellent flow and sanding properties.
5. Successful primer/undercoat for fibre and particle board. Resene Wintergrade Quick Dry seals the waxes used in the board and makes ready for any subsequent paint system.
6. Designed with a low sheen that allows exceptional enamel hold-out.
7. An ideal primer for Matai, Spotted Gum and Totara.
8. An Environmental Choice approved product.

## Limitations

1. Apply in temperatures 2°C - 15°C. Application outside this temperature range may affect curing and application properties. Do not apply at temperatures below 2°C or when temperatures are liable to drop below this during the drying period.
2. Not designed as a first coat over metal surfaces or weak powdery surfaces.

**Exposed bare or cracked timber usually accumulates windblown salt. Before using a totally waterborne system, this salt must be removed by prolonged washing with freshwater. Alternatively, use a solventborne undercoat.**



# WG Quick Dry low temp curing primer undercoat

## Surface preparation

Sand timber surfaces smooth. Clean down thoroughly to remove all dirt, dust and loose material. Any timber that has been exposed to weather for more than one week requires thorough sanding of the surface or treatment with Resene TimberLock (see [Data Sheet D48](#)). Resene TimberLock is strongly recommended for pre-treating new Cedar. Consult Resene for technical advice for coating severely weathered timber.

If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)). Waterblasting at 21,000 kps (3000 psi) is the best surface preparation method prior to painting of weathered cementitious surfaces or galvanised steel.

Efflorescence on masonry must be treated (see [Data Sheet D83](#)).

Existing gloss enamel painted surfaces must be thoroughly sanded to provide a mechanical key for subsequent coats.

*Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.*

## Application

Apply by brush, speed brush, synthetic fibre roller or spray. Spray application is generally not preferred for the first coat.

Apply one to two coats of Resene Wintergrade Quick Dry allowing at least four hours between coats. Lightly sand between coats. For porous surfaces, it may be desirable to thin the first coat with up to 10% clean water.

New paperfaced plasterboard, solid and fibrous plaster and old powdery cementitious surfaces may be sealed with either Resene Sureseal (see [Data Sheet D42](#)) or Resene Broadwall Waterborne Wallboard Sealer (see [Data Sheet D403](#)). Consult Resene.

## Precautions

1. Fill all nailholes and cracked timber after priming.
2. Not recommended for use where severe water staining exists.
3. Resene Wood Primer (see [Data Sheet D40](#)) is recommended for Cedar to hold back staining when light colours are used.



Wintergrade  
Quick Dry SDS

*Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at [www.resene.com/datasheets](http://www.resene.com/datasheets). If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.*

**In Australia**  
PO Box 924, Beenleigh, Qld 4207  
Call 1800 738 383, visit [www.resene.com.au](http://www.resene.com.au)  
or email [advice@resene.com.au](mailto:advice@resene.com.au)

**Resene**  
the paint the professionals use

**In New Zealand**  
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045  
Call 0800 RESENE (737 363), visit [www.resene.co.nz](http://www.resene.co.nz)  
or email [advice@resene.co.nz](mailto:advice@resene.co.nz)