

Resene X-200

acrylic weathertight membrane

Resene X-200 is an acrylic weathertight membrane incorporating the most recent advances in polymer and paint technology. Shows significant advances in the areas of film build, adhesion, penetration, application and durability.

exterior/interior

Typical uses

- Concrete blocks
- Concrete surfaces
- Fibre reinforced cement

Physical properties

Vehicle type	Pure acrylic
Pigmentation	Titanium dioxide/mineral and fibre reinforcement
Solvent	Water
Finish	Eggshell, very fine texture
Colour	Selected Total Colour System, including BS5252, Multi-Finish, Whites & Neutrals and The Range.
Dry time (minimum)	1 hour at 18°C
Recoat time (minimum)	3 hours
Primer required	Yes, dependent on surface
Theoretical coverage	First coat: 5 sq. metres per litre Second coat: 7.5 sq. metres per litre
Dry film thickness	2 coats 180 microns
Usual no. of coats	2; blockwork – 3
Abrasion resistance	Very good
Chemical resistance	Very good
Heat resistance	Thermoplastic
Solvent resistance	Good
Durability	Excellent
Thinning and clean up	Do not thin, clean up with water
VOC	c. 55 grams per litre (see Resene VOC Summary)

Performance and limitations

Performance

1. Remarkable ease of application.
2. Superior void and crack filling properties.
3. Excellent durability. Requires no further 'weathering' coats.
4. An Environmental Choice approved product.

Limitations

1. Old, weathered concrete requires surface conditioning with Resene Sureseal (see [Data Sheet D42](#)).
2. Do not apply at temperatures below 10°C or when it is liable to drop below 10°C during the drying period.
3. Not designed to be used under ponded water.

Please ensure the current Data Sheet and Safety Data Sheet are consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If in doubt contact Resene.



X-200 acrylic weathertight membrane

Surface preparation

Cracked surfaces

Due to its high film build, Resene X-200 will completely fill cracks up to 1mm. For cracks larger than this, apply one coat of Resene Sureseal (see [Data Sheet D42](#)) before filling the crack with a suitable elastomeric paintable sealant.

New cementitious surfaces

Clean down thoroughly to remove all dirt, dust and loose material. Ensure surface is free from oil, grease, form release and curing agents. Glossy surfaces require an additional treatment of Resene ConcreteSeal 3 in 1 (see [Data Sheet D409](#)). Use Resene Limelock (see [Data Sheet D809](#)) on fresh cementitious surfaces to trap any free lime and prevent the appearance of lime staining.

Old cementitious surfaces

If moss and mould are present, treat with Resene Moss & Mould Killer (see [Data Sheet D80](#)). Waterblasting at 21,000 kps (3000 psi) is the best surface preparation method prior to painting weathered cementitious surfaces. If waterblasting is not possible, remove all loose powdery material by thorough wire brushing. Allow to dry and apply one coat of Resene Sureseal (see [Data Sheet D42](#)).

Sanding dust from old lead or chromate based paints or old building materials containing asbestos may be injurious to the health if inhaled or ingested. Seek expert advice if the presence of these materials is suspected.

Application

Airless spray

Use a LTX 523 tip or similar. Use a 30 mesh manifold filter in the system as the fibre reinforcement of Resene X-200 may clog finer filters. Apply two coats.

Brush

Apply two coats at specified rate.

Roller

Use a 12-20mm synthetic fibre roller or texturing roller depending on surface. Apply two coats. When rolling with an extension pole, the maximum extension must be no more than 1.2 metres.

Concrete blocks

Due to regional variations in concrete block standards, two coats may be insufficient for weathertightness. Weathertightness can only be assured when all voids are filled, therefore three coats over block is a safer specification. Brush or roller application is preferred over block and essential for at least the first coat.

Precautions

1. Do not thin – thinning destroys build properties.
2. Ensure correct pre-treatment is used and correct surface preparation is undertaken.



X-200 SDS

Please ensure the current Data Sheet is consulted prior to specification or application of Resene products. View Data Sheets online at www.resene.com/datasheets. If the surface you propose to coat is not referred to by this Data Sheet, please contact Resene for clarification.

In Australia
PO Box 924, Beenleigh, Qld 4207
Call 1800 738 383, visit www.resene.com.au
or email advice@resene.com.au

Resene
the paint the professionals use

In New Zealand
PO Box 38242, Wellington Mail Centre, Lower Hutt 5045
Call 0800 RESENE (737 363), visit www.resene.co.nz
or email advice@resene.co.nz

Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001. Please recycle.