net contents 4 litres

Resene

Lustacryl Commercial Spray Grade

semi-gloss waterborne exterior/interior

USF WITH ADEOUATE VENTILATION. DO NOT EAT, DRINK OR SMOKE WHILE USING.

Read label before use. Keep out of reach of children

This material is quite bland: with vapour, occasional skin

contact and even minor ingestion having negligible hazard.

Repeated skin contact may, and any eye contact will,

cause irritation. Harmful to aquatic life with long lasting effects.

A-LL1490204 5/20

Store in original or correctly labelled container, tightly closed, in a well ventilated area indoors, away from foodstuffs. at an ambient temperature and avoid freezing conditions. Avoid release to the environment.

FIRST AID

PRECAUTIONS

SAFETY PRECAUTIONS

IF SWALLOWED: Rinse mouth, Call a POISON CENTRE, doctor or physician if you feel unwell.

IF ON SKIN (or hair): Rinse skin with plenty of soap and water. If skin irritation or rash occurs get medical advice or attention. IF IN EYES: Rinse cautiously with water for several minutes. If eye irritation persists get medical advice or attention.

IF INHALED: If breathing is difficult, remove to fresh air and keep at rest in a position comfortable for breathing.

When seeking medical advice take this container with you.

Further information can be obtained from AUST: POISONS INFORMATION CENTRE 131 126

or call Resene 1800 738 383.

NZ: NATIONAL POISONS CENTRE 0800 POISON (764 766) or call Resene 0800 737 363.

For use as a decorative/protective coating.

For full technical instructions see Data Sheet D310S

SPILLS: Wear appropriate clothing. Absorb with sand or earth. Collect and seal in properly labelled drums. Do not allow to enter drains or to run off into waterways. Refer to local waste management authority.

CLEANING PAINT EQUIPMENT: Spray out as much paint as possible onto newspaper before washing spray equipment. Dispose of wash-up water onto grassy/unsealed area or into inside sink/basin, NOT into outside stormwater drain where it may harm fish in local waterways.



areas traditionally reserved for solventborne enamels. CoolColours can be used on appropriate projects to assist with curing. Poor ventilation may affect appearance and performance. Non-vellowing and fast set up at higher application heat reflectance. thicknesses with easy water clean up.

Preparation

- Ensure substrates to be coated are in sound condition, dry, free from dirt, dust, loose material, oil (including mineral oil based wood finishes or similar) and salt.
- Remove accumulated windblown salt by washing with Resene most appropriate CoolColour system for your project. Paint Prep and Housewash (see Data Sheet D812)
- If mould is present, treat with Resene Moss & Mould Killer (see Data Sheet D80). Efflorescence on masonry **must be treated** (see • Resene Quick Dry must be used as the first coat on Matai, Cleaner, following the instructions in the Resene Caring for your Data Sheet D83).
- Corrosion on metals should be removed.
- Fill cracks and holes with an appropriate filler after priming.
- All sanding dusts may be harmful and appropriate protection should be worn. In particular dusts from old lead or chromate based paints or old building materials containing asbestos may be injurious to health if inhaled or ingested. Seek expert advice if the presence of these stained or if condensation is likely to form on the surface. materials is suspected.
- and dusted off. Round all sharp edges. Ensure the surface is dry under stressed conditions. Reinforcement with a saturation coat before painting.
- Plasterboard must be prepared to an appropriate level of finish. Either Resene Broadwall Surface Prep & Seal (see Data Sheet D807) Resene Broadwall 3 in 1 (see Data Sheet D810) or Resene Sureseal (see Data Sheet D42) followed by lining paper is recommended in • Repainting - spot prime with the appropriate primer and
- surface contamination. Ensure the surface is dry before painting. and if corrosion is present. Spot prime bare areas.
- This product may be used to paint a wide variety of surfaces. If Apply 1-2 coats in the required colour allowing at least two the surface you propose to paint is unsound or not referred to, try hours between coats. a small test area first or contact your local Resene ColorShop or • If using above an open shower, use Resene Quick Dry as an reseller for advice.

Priming/undercoat

and stress on the surface and, depending on the substrate, may This may require use of an extraction system when painting in vegetable based inks.

- When a CoolColour variant of this product is being used, it **Bathrooms/ensuites/steamy areas** must be used with a primer coat of Resene Quick Dry white (see Steam and condensation can cause surfactants in a new paint film
- Data Sheet D40). Prime other timbers with Resene Quick Dry.
- Spotted Gum, Totara, fibre and particle board.
- Plasterboard and stoppings in non wet areas should be primed
 Maintenance (e.g. Resene Broadwall Waterborne Wallboard Sealer - see Data Sheet D403). Fibrous plaster or plasterboard and stoppings in wet areas should be sealed with Resene Sureseal.
- Hardboard must be sealed (e.g. Resene Sureseal) to promote
 Be PaintWise flow of the topcoats. Use Resene Sureseal if the surface is water
- Some 'soft' plasterboard preparatory products and undercured • For new work ensure the surface is sanded to a smooth finish gypsum based stoppings may not be suitable basecoats for painting of a fully penetrating primer (such as Resene Sureseal) may be required. Use Resene Sureseal or Resene StainLock (see Data Sheet D408) if the surface is water stained or has vellowed due to prolonged exposure to sunlight.
 - undercoat with Resene Quick Dry.
- For repaints thoroughly sand and wash to remove all signs of Consult your Resene ColorShop or reseller for metal primers

- undercoat before topcoating in Resene Lustacryl.
- Maintain good ventilation throughout the drying and post • Dark colours used on exterior surfaces are likely to increase heat application curing period to ensure the paint is properly cured.

Resene Lustacryl Commercial Spray Grade is a semi- reduce its lifespan and increase the level of coating maintenance marginal painting conditions. Do not use gas or diesel burners to gloss waterborne enamel that may be used in all required to maintain an acceptable visual appearance. Resene heat coated area as these produce water that will inhibit drying and

Do not use with Resene Wintergrade Additive.

Data Sheet D45) or Resene Galvo-Prime (see Data Sheet D402) to come to the surface as shiny streaks. This does not harm the immediately below the Resene CoolColour topcoat for optimum paint. To ensure your bathroom/ensuite paint finish keeps looking performance. Refer to Resene ColorShop or reseller staff as to the its best: For the first 5-7 showers wipe steam moisture from walls using a lint free cloth immediately after showering. This will prevent Prime Cedar and timber joinery with Resene Wood Primer (see the moisture on your freshly painted walls bringing surfactants to the surface. If any marks appear use Resene Interior Paintwork paint finish brochure.

after a minimum of four week's drying

See the Resene Caring for your paint finish brochure or the Resene website for full cleaning instructions.

For tips on responsible disposal of paint, cleaning equipment and minimising the impact of your decorating on the environmen see the Resene website. Do not discharge any paint into the environment. Resene PaintWise (NZ) or paintback.com.au (Australia) accepts residual unwanted paint and packaging. Or contact your Local Authority for disposal information.





In Australia: Resene Paints (Aust) Limited 7 Production Ave, PO Box 924, Beenleigh Old 4207 Ph 1800 738 383 Visit www.resene.com.au

In New Zealand: Resene Paints Limited Vogel St, PO Box 38242, Wgtn Mail Centre, Lower Hutt 5045 Ph (04) 577 0500 Visit www.resene.co.nz

Manufactured under a quality system certified as complying with ISO9001 by Telarc SAI, an accredited certification body. Printed on environmentally responsible paper, which complies with the requirements of environmental management systems EMAS and ISO14001, using

Ouick check

Use on: Solid timber doors/ioinery and most surfaces were a hardwearing semi-gloss finish is required. Gloss level: Semi-gloss.

Coverage: Apply to achieve a wet film thickness of 127-152 microns (this will correspond to a coverage of 7-8 square metres per litre)

Dry time: Will vary with film thickness and environmental conditions. Drying is slowed by low temperatures and high humidity. Do not apply under damp conditions.

Recoat time (minimum): 2 hours.

Serviceable after: While the coating is serviceable after 48 hours depending on film thickness, tinter level and drying conditions, it will still be in the curing stage so care needs to be taken with contact and wiping.

Primer required: Yes

Usual number of coats: 1-2

Application method: Airless spray only. This product is not suitable for brush or roller application. Tip recommendation: large areas, doors etc FFLP414; small areas, trim etc FFLP312. Spray pressure 1400psi.

Thinning: In hot conditions may be thinned with up to 5% Resene Hot Weather Additive to slow drying.

Clean up: Water.

Colour range: Selected Resene Total Colour System including BS5252, Multi-finish, Whites & Neutrals and The

Also available as Resene Lustacryl Commercial Spray Grade CoolColour to help reflect heat from exterior surfaces. Application of a Resene CoolColour will reflect more heat than the same colour made using non-cool pigmentation and reduce heat related stress on the substrate; it will not make the painted surface cool to touch. Check with Resene staff whether a Resene CoolColour is right for your project. Before use: Stir well with a wide flat stirrer.

Enjoy the Resene Promise of quality on premium paints. See your Resene ColorShop or the Resene website for a copy.

In every case it is recommended that the appropriate Data Sheet and Safety Data Sheet are consulted prior to application.

Please ensure that use of this product is compatible with the substrate and surface preparation method and that the colour in this container is the same as selected. When using multiple packs of this product on the same project please mix them together before use. Resene does not accept any responsibility for the application of incorrect product to substrate or the application of incorrect products are designed to be used as a system for optimal results. Substitution may cause substandard results or system failure. For further painting advice and information, call 1800 738 383 (AUST), 0800 737 363 (NZ) or visit the Resene website.