

Resene product labels are updated from time to time. This label is provided as a guide for this product and may differ from the label on the container you purchase. Please discuss your project with your local Resene ColorShop team or reseller to ensure you have the right products to give you the best quality finish for your specific project.

Resene

Water Lockout and Fibreglass Pot Sealer

waterborne exterior/interior

KEEP OUT OF REACH OF CHILDREN



9 4 18 0 2 2 10 0 4 0 9

LL3801050F 1-25

**SHAKE WELL
BEFORE USE**

Quick check

Resene Water Lockout and Fibreglass Pot Sealer is a high build liquid watertight membrane based on a urethane modified bitumen emulsion. It cures to a seamless highly elastic and durable film that adheres well to most substrates to block water ingress.

Use on: Fibreglass pot interiors, wood planter box interiors, masonry walls, in situ concrete walls/floors, plastered/rendered walls and retaining walls.

Gloss level: Satin.

Typical coverage: One square metre per litre per coat. Additional coats may be required to achieve this spreading rate, especially on vertical surfaces.

Dry time (minimum): 1-3 hours at 20°C. Full dry 3-4 days at 20°C.

Usual number of coats: One good coat for fibreglass pots. Two for other surfaces.

Application method: Brush for small areas. For larger areas, roller (high solids sleeve) or squeegee (flat surfaces only).

Thinning: Do not thin.

Clean up: Water while wet. Once dry, use Resene Thinner No.2.

Colour range: Brown when wet, black when dry. Recommended for non aesthetic areas.

SAFETY PRECAUTIONS Read label before use. This material is quite bland; with vapour, occasional skin contact and even minor ingestion having negligible hazard. Repeated skin contact may, and any eye contact will, cause irritation.

PRECAUTIONS USE WITH ADEQUATE VENTILATION. DO NOT EAT, DRINK OR SMOKE WHILE USING.

Store in original or correctly labelled container, tightly closed, in a well-ventilated area indoors, away from foodstuffs, at an ambient temperature and avoid freezing conditions.

FIRST AID

IF INHALED: If breathing is difficult, remove to fresh air and keep at rest in a position comfortable for breathing

IF SWALLOWED: Rinse mouth. Call a POISON CENTRE, doctor or first aider if you feel unwell.

IF ON SKIN (or hair): Rinse skin with plenty of soap and water. If skin irritation or rash occurs get medical advice or attention.

IF IN EYES: Rinse cautiously with water for several minutes. If eye irritation persists get medical advice or attention.

Further information can be obtained from

AUST: POISONS INFORMATION CENTRE 131 126 or call Resene 1800 738 383. **NZ:** NATIONAL POISONS CENTRE 0800 POISON (764 766) or call Resene 0800 737 363.

SPILLS: Wear appropriate protective clothing. Absorb with sand or earth. Collect and seal in properly labelled drums. Do not allow to enter drains or to run off into waterways. Refer to local waste management authority.

CLEANING PAINT EQUIPMENT: Brush/roll out as much paint as possible onto newspaper before washing brushes and rollers. Minimise water used for washing. Dispose of wash-up water onto grassy/unsealed area away from food crop growing areas and NOT into outside stormwater drain where it may harm fish in local waterways. See resene.com/cleanup for cleaning instructions.

Preparation

- Ensure the surface is in sound condition, dry and free from dust, dirt and loose materials, oil and grease.
- Remove oil and grease from surface using Resene Paint Prep and Housewash (see Data Sheet D812).
- Pre-dampen hot, dry or very absorbent surfaces, such as concrete, with water before application.
- If the surface you propose to treat is unsound or not referred to, try a small test area first or contact your local Resene ColorShop or reseller.

Application

- Apply each coat at right angles to the dry preceding coat.
- For flat horizontal surfaces, use a pour and spread application technique with a squeegee to achieve a uniform wet film thickness and to fill voids.
- May be sprayed but requires specialist spray equipment. Consult Resene Technical Services for advice when considering spray application.
- On all weak points such as cracks, around pipe penetrations or at the wall/floor junction use a woven fibreglass

cloth between the first two coats of Resene Water Lockout. Roll the fibreglass cloth into the first coat while wet and leave to fully dry before applying the second coat of Resene Water Lockout.

- Maintain good ventilation throughout the drying and curing period to ensure the treatment is properly cured. Poor ventilation may inhibit curing and performance.
- Do not use as a curing membrane on surfaces to be painted.

For further painting advice and information, call 1800 738 383 (AUST), 0800 737 363 (NZ) or visit the Resene website.

Resene

the paint the professionals use

In Australia: Resene Paints (Aust) Ltd
7 Production Ave, PO Box 918, Ashmore City, QLD 4214
Ph 1800 738 383 Visit resene.com.au

In New Zealand: Resene Paints Ltd
Vogel St, PO Box 38242, Wgtn Mail Centre,
Lower Hutt 5045 Ph (04) 577 0500 Visit resene.co.nz